ULDB TDI "PROTOTYPE BOARD"

Thermal Test Procedure

Version 1.0

March 8, 2000

Prepared by: William Mocarsky

Signature Sheet

Prepared By: _		Date:
	William Mocarsky/566	
Approved By:_		Date:
	Kevin Ballou/566	
	TDI System Engineer	
Concur: _		Date:
	Dwayne Morgan/584	
	TDI Product Development Lead	

CHANGE INFORMATION PAGE

Version	Date	Description	Affected Pages
1.0	03/08/2000	Original.	All

1. Overview

This document describes the ULDB TDI Thermal Test that is to be performed on the prototype TDI card

1.1 Test Purpose

The purpose of this test is to demonstrate that all functions of the TDI board work properly under varying temperature conditions and to measure the thermal characteristics of the TDI board at temperature extremes.

1.2 Test Organization

As illustrated in Figures 1.2-1, 1.2-2 and 1.2-3, this test consists of

- a. 1 survival cycle demonstrating the TDI's ability to turn on/off at the temperatures specified in the TDI requirements document,
- b. 1 survival cycle demonstrating the TDI's ability to turn on/off at -40C and +80C degrees

and

c 4 thermal cycles to demonstrate the operability of the TDI board at -40Cthrough +80Cdegrees.

Note that this test may be stopped and restarted to minimize 24 hour operations. The test may be stopped and restarted after steps 3.3, 3.4, 3.5 and 3.6. If the test is suspended, the verification of the test setup as detailed in steps 2.2 through 3.1 must be performed again.

1.3 Applicable Documents

The following documents are applicable to this document:

TDI "LDB MODE" System Functional Test Procedure

The Ultra Long Duration (ULDB) TDRSS Data Interface (TDI Requirements
And Functional Specifications, Version 1.0.0 September, 1999

Ultra Long Duration Balloon (ULDB) TDRSS Data Interface (TDI) Test Plan December,1999

Ultra Long Duration Balloon (ULDB) TDRSS Data Interface (TDI)

Interface Control Document January, 2000

Electrostatic Discharge Control, NASA-STD-8739.7 December, 1997

ULDB Environmental Test Guidelines November, 1999

TDI "ULDB MODE" System Functional Test Procedure March, 2000

1.4 Configuration Management

This document shall be managed by the ULDB TDI development team. Changes to this test procedure shall require the approval of the Ultra Long Duration (ULDB) TDRSS Data Interface (TDI) Product Development Lead.

During the execution of this test, typographical and procedural flow changes may be made at the discretion of the TDI Test Engineer. The changes will then be submitted for approval at the conclusion of the test.

March, 2000

After test execution, the completed test procedure shall be maintained by the TDI team as an "As Run" procedure.

1.5 Quality Assurance

This test will not be monitored by quality assurance. However, prior to the execution of this test, the test engineer shall verify the test configuration, test equipment calibration, documentation and ESD certification of test personnel. After this initial verification, testing shall commence. If anomalies are encountered during the execution of this test, the TDI Systems Engineer shall be notified. The execution of this test procedure shall be documented on a GSFC Work Order Authorization (WOA). Any anomalies shall be logged as a Non-Conformance Report (NCR) as per the GSFC QMS. At the conclusion of the test, the TDI Systems Engineer shall review the test results and approve any typographical changes or procedural flow deviations.

2.	Test	Setup

Omega Thermocouple System 3 GN2 Tanks with regulator and tubing

GN2 Flow Meter

_			
2.1 Test Personnel			
This test shall be performed by	by one or more test conductors	:	
Test Conductor # 1			
Test Conductor #2			
2.2 Documentation Requir	ed		
	ed copy of this test procedure, em Functional test procedures a		
All test procedures have been	signed:		Check
A GSFC WOA is in place.	WOA Number:	Event #:	
2.3 Equipment Required			
The following equipment is re	equired for this test. Refer to the	he test plan for co	nfiguration details.
DC 104 decede accept accept accept	OD "Si ska like CDM"	Cal ID	Cal Date
PC-104 development system TDI Board	OR THIght like CDM		
Bit Sync with viterbi decoder			
HP 8015A Pulse Generator Firebird 6000 Communication	ıs Analyzer		
Phillips PM6680B High Reso Tenny BTC 942 Thermal Cha	lution Prog Timer/Counter		

ULDB TDI "Diagnostic Software" Power supply	
Digital MultiMeter	
All required calibratable test gear is in calibration	Check:
2.4 Test Configuration	
The test set-up is configured as in Figure 2-4-1.	Check:
2.5 ESD Precautions	
All TDI hardware shall be handled in compliance with NASA-STD-873 Control. All test personnel shall have current ESD certification. All te ESD certified and test area shall be maintained between 30% and 70% has been shall be maintained between 30% and 70% and 70% has been shall be maintained between 30% and 70% and	est a reas and benches shall also be
Wrist straps shall be worn at all times while either handling or within 3 fee wrist straps shall be verified for resistance at least 1 time each day. No worn by test personnel when within 3 feet of the TDI board.	
Test facility is between 30% and 70% humidity.	Check:
Test personnel have ESD certification.	Check:
Wrist straps are functioning.	Check:
Non-static generating clothing is worn.	Check:
3. Thermal Test Procedure	
3.1 Test Initialization	
TEST ITEM IDENTIFICATION	
(1) Verify that the PC 104 development system or "flight like CDM" $$	is powered off.Check:
(3) Record the serial number of the TDI board. SN:	Check:
(4) Record the FPGA Silicon Signature Number: Sig Num:	Check:
(5) Verify that the TDI ULDB Mode select jumper is removed.	Check:
(6)Record TDI board IRQ and Base Address settings. IRQA: IRQB:	~ ·
Base Addr:	Check:
<u>GSE SET UP</u>	
(7) Verify that the TDI GSE rack is powered off.	Check:
(8) Verify that the GSE telemetry cable is connected to TDI connecto	r P4 Check:
(9) Verify that the GSE Discrete Deck Select cable is connected to TDI of	connector P3Check:

(10) Verify	that the GSE test point cables are connected to TDI connectors P5 and P6	6Check:			
(11) Power	the GSE Rack	Check:			
(12) Verify	(12) Verify the Bit Sync Stored format settings.				
a.	Enter 130 on bit sync key-pad and verify Data Rate = 3.000*10**5 Input Code = 0 (NRZ-L) FEC Code = 2 (BPSK-D) FEC Rate=1 (1/2)				
b.	Enter 131 on bit sync key-pad and verify Data Rate = 1.500*10**5 Input Code = 0 (NRZ-L) FEC Code = 0 (OFF) FEC Rate= N/A				
c.	Enter 132 on bit sync key-pad and verify Data Rate = 2.000*10**3 Input Code = 0 (NRZ-L) FEC Code = 2 (BPSK-D) FEC Rate = 1 (1/2)				
d.	Enter 133 on bit sync key-pad and verify Data Rate = 1.000*10**3 Input Code = 0 (NRZ-L) FEC Code = 0 (OFF) FEC Rate = N/A				
e.	Enter 134 on bit sync key-pad and verify Data Rate = 1.000*10**5 Input Code = 0 (NRZ-L) FEC Code = 2 (BPSK-D) FEC Rate = 1 (1/2)				
f.	Enter 135 on bit sync key-pad and verify Data Rate = 5.000*10**4 Input Code = 0 (NRZ-L) FEC Code = 0 (OFF) FEC Rate = N/A				
g.	Enter 136 on bit sync key-pad and verify Data Rate = 1.5000*10**5 Input Code = 1(NRZ-M) FEC Code = 0 (OFF) FEC Rate = N/A				
h.	Enter 137 on bit sync key-pad and verify Data Rate = 1.500*10**5 Input Code = 3 (BiO-L) FEC Rate = 0 (OFF) FEC Rate = N/A	Check:			

(13) Verify the RS232C terminal cable is connected to the COM1 processor port	Check:
(14) Verify the PC Keyboard is connected.	Check:
(15)Verify proper setup of the power supply by: Disconnect the power cable from the PC 104 stack Turn on the power supply Using calibrated DMM, set voltage as measured at pin 1 to +5V Connect power cable to PC104 stack	Check:
CHAMBER SET UP (16) Verify that 3 fully charged GN2 tanks are available.	Check:
(17) Connect 1 GN2 tank to chamber. Verify pressure is >1800PSI	Check:
(18) Verify that the drip pan is in place.	Check:
(19) Verify that all cable feed-throughs are blocked and sealed.	Check:
(20) Turn on the chamber.	Check:
(21) Verify the following chamber parameters:	Check:

ITEM	CONTENTS	COMMENTS
IN	Rt.d	
C_F	С	Degrees C
RL	-73.3	
RH	200.0	
Ot 1	Ht	
Hys1	1.5	
Ot2	CL	
Hys2	1.5	
Ot3	AL	
AL1	Pr	
Lat 1	NLa	
Hys3	1.5	
Oth	AL	
AL2	Pr	
LAT2	NLA	
Hys4	1.5	
Rtd	J15	
PtYp	RATE	Rates instead of times
95d	0.0	
Pout	Cont	
PsLp	StPt	
BAUD	9600	
Data	7o	
Prot	FULL	
Addr	0	

The following are the settings in the stored Profiles of the Tenney Chamber. The items in steps 1-13 are set to reflect the "Specification Survivability "cycle. Note that the 5 degree/minute ramp rate is not achievable using Tenney Chamber in B23 Room E422. It achieves 2 degrees/minute when going cool at temperatures below 0 degrees. Also note that the HOT TRANSITION rates (Cold-Hot) are varied in attempt to reduce condensation. A preprogrammed overshoot of the desired temperatures during cycles 3-6 are planned in attempt to get the TDI board to the desired temperature more quickly.

Profile Step Number	Profile Contents	Comments
1	EnSp=85,Rate=5	Ambient to 85deg, 5deg/min
2	End=Hold	Wait
3	EnSp=50, Rate=5	85deg->50 deg, 5 deg/min
4	End=Hold	Wait
5	EnSp=-55, Rate=5	Transition to -55, rate not
		achievable
6	End=Hold	Wait
7	EnSp=-30, Rate=3	-55 to -30 @ 3deg/min. Rate
		chosen to give board time to
		track.
8	End=Hold	Wait
9	EnSp=-5, Rate=3	-30 to −5 @3 deg/min. Rate to
		get board to track.
10	EnSp=5, Rate=1.5	-5 to +5 @1.5 deg/min to
		minimize chance of condensation.
11	EnSp=24, Rate=3	Transition to Ambient @3 deg
12	End=HOLD	Wait
13	END=OFF	Used to end a test for the day
14	EnSp=85, Rate5	Overshoot Hot @5 deg/Min
15	Soak Hour=0, Min=5, Sec=0	Hold 85 for 5 minutes to give
		board a chance to get close to 80
		deg
16	EnSp=80, Rate=5	85 to 80 deg – Hot Plateau
17	End=Hold	Wait
18	EnSp=0, Rate=4	Transition to 0 deg @4 deg/min
		should be attainable
19	EnSp=-45, Rate=1.5	Overshoot Cold Plateau by 5 deg.
		Rate chosen to see that we getr
		there.
20	Soak Hours=0, Mins=5, Sec=0	Soak at -45 to give TDI board
		chance to get to -40.
21	EnSp=-40, Rate=3	Cold Plateau
22	End=Hold	Wait
23	JS=9, JL=1	Jump to step 9, the transition to
		ambient.
24	End=hold	Just in case

DATA ACQUISITION SETUP

	(aa)	X /: C-	. 41 1 4:	_ £1_	thermocouple	1.
- (//	verni	v ine location	i or each	Thermocolinie	nsear

Check:____

- 1 TDI Board #1 FPGA
- 2 TDI Board #1 External Edge
- 3 TDI Board #1 External Edge
- 4 Chamber Wall Left

	5 6	Chamber Wall - Right PC-104/"Flight-like" CDM processor	
(23)	Verify	that all unused thermocouples are securely tied down in the chamber	Check:
(24)	Verify	all thermocouples read current chamber temperature within +/- 5 degr	eesCheck:
(25)	Turn t	the chamber off.	Check:
		CLOSEOUT hat the GSE and Chamber are grounded	Check:
(27)	Verify	that the chamber door is closed.	Check:
(28)	Verify	the chamber main power is on.	Check:
(29)	Power	the PC-104/'Flight-like" CDM system.	Check:
(30)	Ver	he diagnostic software. ify FIFO LOAD MODE = NORMAL ify Mission Mode = ULDB	Check:
(31)	Run Se	ections 3.2, 3.3 and 3.13 of the TDI "ULDB MODE" System Function	onal Test. Check: Circle:PASS/FAIL
(32)	Power	down the PC-104/'Flight-like" CDM	Check:
3.2 (Contin	uous Temperature and GN2 Monitoring	
All to minu		tures shall be read and recorded every 5 minutes. GN2 pressures shall Check	be read every 10
		†1 (Specification Survivabilty) Test GN2 purge flow rate to 10 cfh	Check:
		GN2 tank pressure and flow rate on the attached form every 10 minutes 00 psi, disable the drained tank and enable a charged tank.	•
			Check:
(3) 7	Turn or	n chamber(OVER TEMP)	Check:
(4) A	At the t	hermal chamber, run the profile starting at Profile Step 1.Date:,	Time: Check:
(5) N	Note wh	nen TCs 2-5 average 85deg C +/- 2C. Date:	Time:
(6) V	Wait 2	hours.	Check:
(7) (On the	thermal chamber, run profile starting at Profile Step 3	Check:
(8) \	When T	CCs 2-5 average 50deg C +/- 2C note the date and time.Date:	Time:
(9) A	Apply p	ower to the "Flight-like" CDM.	Check:

(10)Run the diagnostic software. Verify FIFO LOAD MODE=NORMAL Verify MISSION MODE=ULDB	
If different, toggle settings until get the above modes	Check:
(11)Execute Step 3.2 of ULDB MODE SFT to verify HARD RESET status. No powerup. Date:	te Time of successful Time: Check:
(12)Repeatedly execute steps 3.3 thru 3.19 of the ULDB MODE SFT for at least 2 time of completion. Issue pulse command using HP pulse generator to selection iterations. Do not issue pulse command after the last iteration.	ct PCM-A between
(13)Power down the "Flight-like" CDM.	Check:
(14)On the thermal chamber, run profile starting at Profile Step 5	Check:
(15)Set GN2 flow to 5cfh.	Check:
(16)When TCs 2-5 average –55deg C +/- 2 C, note the date and time.Date:	Time: Check:
(17)Wait 2 hours.	Check:
(18)On the thermal chamber, run profile starting at Profile Step 7.	Check:
(19)When TCs 2-5 average –30deg C +/- 2C, note date and time. Date:	Time: Check:
(20)Apply power to the "Flight-like"CDM.	Check:
(21)Run the diagnostic software. Verify FIFO LOAD MODE=NORMAL Verify MISSION MODE=ULDB If different, toggle settings until get the above modes	Check:
(22)Execute Step 3.2 of ULDB MODE SFT to verify HARD RESET status. No powerup. Date:	te Time of successful Time: Check:
(23)Repeatedly execute steps 3.3 thru 3.19 of the ULDB MODE SFT for at least 2 time of completion. Issue pulse command using HP pulse generator to sele iterations. Do not issue pulse command after the last iteration.Stop Date:	ect PCM-A between
(24)At the thermal chamber, run profile starting at Profile Step 9 .Date:	Time: Check:
(25)Set GN2 flow to 10cfh	Check:
(26)Patch B1TI M to RS#1 S0 IN	Check:

(27) Verify PCM-B discrete deck is selected by reading I/O Port 0x01 and verthe test FAILED.	erifying msb = 1. If it is not 1, Check:
	Circle:PASS/FAIL
(28)Enter 134 on bit sync keypad to configure bit sync as follows: Data Rate:100Ksymbols/sec Input Code:NRZ-L FEC Code:BPSK-D Rate:1/2	
1	Check:
(29)Place TDI Board in FIFO-ENCODED at 50Kbps (100Ksymbols/secontion of the diagnostic software. Enter BERT 6.BIN for the file name Toggle ENCODING to ENCODED Toggle SOURCE to FIFO Change clock register to 0x04c) by selecting FLOW DATA
Change clock register to 0x04c	Check:
(30)Press RESTART on FIREBIRD 6000.	Check:
(31)When TCs 2-5 averages 24deg +/- 2 deg , note Date	: Time: Check:
(32)Record Block Errors: BLOCKS:	ors NON_ZERO or BLOCK is
Zero of the Phezika Birve Boss ngh is hi, the test funed.	Check:
	Circle:PASS/FAIL
(33)Verify PCM-B discrete deck is selected by reading I/O port 0x01 and v the test FAILED.	erifying msb=1. If it is not 1, Check: Circle: PASS/FAIL
(34)Select PCM-A by generating pulse command using HP pulse generator I/O port 0x01 and verifying msb is ZERO.	r. Verify A selected by reading Check: Circle:PASS/FAIL
(35)Place TDI Board in FIFO-ENCODED at 50Kbps (100Ksymbols/secontion of the diagnostic software. Enter BERT 6.BIN for the file name Toggle ENCODING to ENCODED Toggle SOURCE to FIFO Change clock register to 0x04c) by selecting FLOW DATA
Change clock register to 0x04c	Check:
(36)Press RESTART on FIREBIRD 6000.	Check:
(37)Wait 2 minutes.	Check:
(38)Record Block Errors: BLOCKS: If Block Errors Zero or the FIREBIRD SYNC LOSS light is lit, the test failed.	
-	Check: Circle:PASS/FAIL
(39)Either suspend test or continue on by:	

a. Stop Test by powering down GSE, power down the CDM, opening chamber door, stopping GN2 flow, executing Profile Step 13 and powering down the chamber. Check:___ OR b. Continue with step 3.4 Check:___ 3.4 Cycle #2 (Extended Survivability) Test Check:___ (1) Turn off the Chamber temperature control. (2) Modify the EnSp parameters at the following steps to reflect the "extended range survivability test Step #3 set EnSp = 80. Step #7, set EnSp=-40 Check:___ (3) Set the GN2 purge flow rate to 10 cfh. Check: (4) Log the GN2 tank pressure and flow rate on the attached form every 10 minutes. If tank pressure is below 300 psi, disable the drained tank and enable a charged tank. Check:___ (5) If chamber is not on, turn on chamber. Check: (6) At the thermal chamber, run the profile starting at Profile Step 1.Date:_____, Time: Check:__ (7) Note when TCs 2-5 average 85deg C +/- 2C. Date:____ Time:__ Check: (8) Wait 2 hours. Check:___ (9) On the thermal chamber, run profile starting at Profile Step 3 Check:__ (10) When TCs 2-5 average 80deg C +/- 2C note the date and time. Date:__ Time: Check:__ (11) Apply power to the "Flight-like" CDM. Check:__ (12)Run the diagnostic software. Verify FIFO LOAD MODE=NORMAL Verify MISSION MODE=ULDB If different, toggle settings until get the above modes Check:_ (13)Execute Step 3.2 of ULDB MODE SFT to verify HARD RESET status. Note Time of successful Date:_____ Time:____ Check:

(14)Repeatedly execute steps 3.3 thru 3.19 of the ULDB MODE SFT for at least 2 hours. Note date and time of completion. Issue pulse command using HP pulse generator to select PCM-A between

iterations. Do not issue pulse command after the last iterationStop Date:_

__ Time:____ Check:___ Circle:PASS/FAIL

(15)Power down the "Flight-like" CDM.	Check:
(16)On the thermal chamber, run profile starting at Profile Step 5.	Check:
(17)Set GN2 flow to 5 cfh	Check:
(18)When TCs 2-5 average –55deg C +/- 2 C, note the date and time.Date:	Time: Check:
(19)Wait 2 hours.	Check:
(20)On the thermal chamber, run profile starting at Profile Step 7.	Check:
(21)When TCs 2-5 average –40deg C +/- 2C, note date and time. Date:	Time: Check:
(22)Apply power to the "Flight-like"CDM.	Check:
(23)Run the diagnostic software. Verify FIFO LOAD MODE=NORMAL Verify MISSION MODE=ULDB If different, toggle settings until get the above modes	Check:
(24)Execute Step 3.2 of ULDB MODE SFT to verify HARD RESET status. N powerup. Date:	Time: Check:
(25)Repeatedly execute steps 3.3 thru 3.19 of the ULDB MODE SFT for at least time of completion. Issue pulse command using HP pulse generator to selecterations. Do not issue pulse command after the last iterationStop Date:_	ect PCM-A between
(26)At the thermal chamber, run profile starting at Profile Step 9. Date:	Time: Check:
(27)Set GN2 flow rate to 10 cfh	Check:
(28)Patch B1TLM to BS#1 S0 IN	Check:
(29) Verify PCM-B discrete deck is selected by reading I/O Port $0x01$ and verifying the test FAILED.	ig msb = 1. If it is not 1, Check: Circle:PASS/FAIL
(30)Enter 134 on bit sync keypad to configure bit sync as follows: Data Rate:100Ksymbols/sec Input Code:NRZ-L FEC Code:BPSK-D Rate:1/2	
	Check:
(31)Place TDI Board in FIFO-ENCODED at 50Kbps (100Ksymbols/sec) by so option of the diagnostic software. Enter	electing FLOW DATA

BERT 6.BIN for the file name Toggle ENCODING to ENCODED Toggle SOURCE to FIFO

Change clock register to 0x04c		Check:
(32)Press RESTART on FIREBIRD 6000.		Check:
(33)When TCs 2-5 average 24 deg +/2 deg , note	Date:	Time: Check:
(34)Record Block Errors: BLOCKS: Zero or the FIREBIRD SYNC LOSS light is lit, the te	If Block Errors NC st failed.	
		Check: Circle:PASS/FAIL
(35)Verify PCM-B discrete deck is selected by reading I/O p the test FAILED.	ort 0x01 and verifying	ng msb=1. If it is not 1, Check: Circle: PASS/FAIL
(36)Select PCM-A by generating pulse command using HF I/O port 0x01 and verifying msb is ZERO.	P pulse generator. Vo	e rify A selected by reading Check: Circle:PASS/FAIL
(37)Place TDI Board in FIFO-ENCODED at 50Kbps (100 option of the diagnostic software. Enter BERT 6.BIN for the file name Toggle ENCODING to ENCODED Toggle SOURCE to FIFO	OKsymbols/sec) by se	electing FLOW DATA
Change clock register to 0x04c		Check:
(38)Press RESTART on FIREBIRD 6000.		Check:
(39)Wait 2 minutes.		Check:
(40)Record Block Errors: BLOCKS: Zero or the FIREBIRD SYNC LOSS light is lit, the te	If Block Errors N st failed.	ON_ZERO or BLOCK is Check: Circle:PASS/FAIL
(41)Either suspend test or continue on by:		
a. Stop Test by powering down GSE, execute prochamber door, stopping GN2 flow and powering of		own the CDM, opening
		Check:
OR b. Continue with step 3.5		Check:

3.5 Cycles 3-4 ULDB MODE Extended Temperature Tests

(1)	Set the GN2 purge flow rate to 10 cfh.	Check:	
(2)	Log the GN2 tank pressure and flow rate on the attached form every 10 m below 300 psi, disable the drained tank and enable a charged tank.	minutes. If tank press	sure is
		Check:	
(3)	If chamber is not on, turn on chamber.	Check:	
(4)	If CDM is NOT powered, power up the "Flight-like" CDM, run the did Verify FIFO LOAD MODE=NORMAL Verify MISSION MODE=ULDB If different, toggle settings until get the above modes Execute Step 3.2 of ULDB MODE SFT to verify HARD RESET st		/FAIL
(5)	Enter 130 on bit sync keypad to configure bit sync as follows: Data rate = 300Ksymbols/Sec Input Code = NRZ-L FEC Code = BPSK-D Rate: ½	Check:	
(6)	Patch A1TLM to BS#1 S0 IN	Check:	
(7)	Verify PCM-A discrete deck is selected by reading I/O Port $0x01$ and verthe test FAILED		not 0,
(8)	Put TDI board in FIFO – Encoded at 150Kpbs (300Ksymbols/sec) by secoption of the diagnostic software. Enter BERT6.BIN for the file name Toggle ENCODING to ENCODING Toggle SOURCE to FIFO Change clock register to 0x028	electing the FLOW D	
(9)	Select BERT pattern 63. Press RESTART on the FIREBIRD 6000	Check:	
	Hot Transition (+80 deg C) Powered		
(10)At the thermal chamber, run the profile starting at Profile Step 14.Date:	, Time: Check:	
(11)Note when TCs 2-5 average 80deg C +/- 2C. Date:	Time: Check:	
(12	Record Block Errors: BLOCKS: If Block Errors Zero or the FIREBIRD SYNC LOSS light is lit, the test failed.	s NON_ZERO or BLC Check: Circle:PASS/I	

(13)Execute steps 3.3 thru 3.19 of the ULDB MODE SFT. N		of completionTime::
	Stop Date	Check:
		Circle:PASS/FAIL
COLD Transition (-40deg C) Powered		
(14)On the thermal chamber, run profile starting at Profile Ste	ер 18.	Check:
(15)Set GN flow rate to 5 cfh		Check:
(16)Patch B1TLM to BS#1 S0 IN		Check:
(17) Verify PCM-B discrete deck is selected by reading I/O Port (the test FAILED.	0x01 and verifying	msb = 1. If it is not 1, Check: Circle:PASS/FAIL
(18)Enter 134 on bit sync keypad to configure bit sync as foll Data Rate:100Ksymbols/sec Input Code:NRZ-L FEC Code:BPSK-D Rate:1/2	lows:	
Rate. 1/2		Check:
(19)Place TDI Board in FIFO-ENCODED at 50Kbps (100Ksy option of the diagnostic software. Enter BERT 6.BIN for the file name Toggle ENCODING to ENCODED Toggle SOURCE to FIFO Change clock register to 0x04c	ymbols/sec) by seld	ecting FLOW DATA
		Check:
(20)Press RESTART on the FIREBIRD 6000		Check:
(21)When TCs 2-5 average –40deg C +/- 2 C, note the date and	l time.Date:	Time: Check:
(22)Record Block Errors: BLOCKS: If Zero or the FIREBIRD SYNC LOSS light is lit, the test fa	FBlock Errors NON iiled.	N_ZERO or BLOCK is Check: Circle:PASS/FAIL
(42)Verify PCM-B discrete deck is selected by reading I/O port (the test FAILED.	0x01 and verifying	msb=1. If it is not 1, Check: Circle: PASS/FAIL
(23)Select PCM-A by generating pulse command using HP pulse I/O port 0x01 and verifying msb is ZERO.	e generator. Verify	A selected by reading Check: Circle:PASS/FAIL
(24)Execute steps 3.3 thru 3.19 of the ULDB MODE SFT. N		of completion. Time: :

	Circle:PASS/FAIL
HOT Transition (Powered)	
(25)Set GN2 flow rate to 10 cfh.	Check:
(26)On the thermal chamber, run profile starting at Profile Step 23.	Check:
(27)Verify PCM-B discrete deck is selected by reading I/O Port $0x01$ and verifying n the test FAILED.	nsb = 1. If it is not 1, Check: Circle:PASS/FAIL
(28)Enter 131 on bit sync keypad to configure bit sync as follows: Data Rate:150Kb/sec Input Code:NRZ-L FEC Code:OFF Rate:1/2	
Natio. 172	Check:
(29)Patch B2TLM to BS#1 S0 in	Check:
(30)Place TDI Board in FIFO-UNENCODED at 150Kbps (100Ksymbols/sec) by selection of the diagnostic software. Enter BERT 6.BIN for the file name Toggle ENCODING to RAW Toggle SOURCE to FIFO Change clock register to 0x028	lecting FLOW DATA
	Check:
(31)Press REST ART on the FIREBIRD 6000	Check:
(32)When chamber temperature display indicates 24 degrees attained and the RUI Profile Step 14.	N light is not lit, run Check:
(33)When TCs 2-5 averages 80deg C +/- 2C, note date and time. Date:	Time: Check:
(34)Set GN2 flow rate to 5 cfh	Check:
(35)Record Block Errors: BLOCKS: If Block Errors NON Zero or the FIREBIRD SYNC LOSS light is lit, the test failed.	ZERO or BLOCK is Check: Circle:PASS/FAIL
(43)Verify PCM-B discrete deck is selected by reading I/O port 0x01 and verifying the test FAILED.	msb=1. If it is not 1, Check: Circle: PASS/FAIL
(36)Select PCM-A by generating pulse command using HP pulse generator. Verify I/O port 0x01 and verifying msb is ZERO.	A selected by reading Check: Circle:PASS/FAIL

(37)Execute steps 3.3 thru 3.19 of the ULDB MODE SFT. Note date St	and time of completion. op Date: Time::
	Check: Circle:PASS/FAIL
COLD Transition (Powered)	
(38)On the thermal chamber, run profile starting at Profile Step 18.	Check:
(39)Select PCM-A discrete deck by generating discrete deck pulse con Verify PCM-A is selected by reading I/O prot 0x01 and verifying m test failed.	
(40) Enter 131 on bit sync keypad to configure bit sync as follows: Data Rate:150Kb/sec Input Code:NRZ-L FEC Code:OFF Rate:1/2	
1	Check:
(41)Patch A2TLM to BS#1 S0 IN	Check:
(42)Place TDI Board in FIFO-UNENCODED at 150Kbps (100Ksym option of the diagnostic software. Enter BERT 6.BIN for the file name Toggle ENCODING to RAW Toggle SOURCE to FIFO Change clock register to 0x028	bols/sec) by selecting FLOW DATA
	Check:
(43)Press RESTART on the FIREBIRD 6000	Check:
(44)When TCs 2-5 average –40deg C +/- 2C, note date and time. D	rate: Time: Check:
(45)Record Block Errors: BLOCKS: If Block Zero or the FIREBIRD SYNC LOSS light is lit, the test failed.	Errors NON_ZERO or BLOCK is
	Check:Circle:PASS/FAIL
(46)Verify A selected by reading I/O port $0x01$ and verifying msb is ZI FAILED	ERO. If not ZERO then the test Check: Circle:PASS/FAIL
(47)Execute steps 3.3 thru 3.19 of the ULDB MODE SFT. Note date	and time of completion. op Date: Time::
	Check:Circle:PASS/FAIL
Ambient Transition (Powered)	
(48)Set GN2 flow rate to 10 cfh.	Check:

(49)On thermal chamber, run profile starting at Profile Step 23 to bring chambe	r to Ambient. Check:
(50)Select PCM-A discrete deck by generating discrete deck pulse command usin Verify PCM-A is selected by reading I/O prot 0x01 and verifying msb is ZER0 test failed.	
(51) Enter 130 on bit sync keypad to configure bit sync as follows: Data Rate:300Ksymbols/sec Input Code:NRZ-L FEC Code:BPSK-D Rate:1/2	
	Check:
(52)Patch A1TLM to BS#1 S0 IN	Check:
(53)Place TDI Board in BERT UNENCODED at 150Kbps by selecting FLOW diagnostic software. Enter BERT 6.BIN for the file name Toggle ENCODING to ENCODING Toggle SOURCE to BERT Change clock register to 0x028	DATA option of the Check:
(54)Configure BERT generator for 2047 test pattern. Press RESTART on the FIF	REBIRD 6000 Check:
(55)When TCs 2-5 average 24deg C +/- 2C, note date and time. Date:	Time: Check:
(56)Record Block Errors: BLOCKS: If Block Errors NOT Zero or the FIREBIRD SYNC LOSS light is lit, the test failed.	N_ZERO or BLOCK is Check: Circle:PASS/FAIL
(57) Verify A selected by reading I/O port $0x01$ and verifying msb is ZERO. If msb test FAILED.	is not ZERO, then the Check: Circle:PASS/FAIL
(58)Execute steps 3.3 thru 3.19 of the ULDB MODE SFT. Stop Date:_	Time: Check: Circle:PASS/FAIL
(59)Power down "Flight-like" CDM.	Check:
(60)Stop GN2 flow.	Check:
(61)Run Profile Step 13 to terminate control of chamber.	Check:
(62)Either suspend test or continue to LDB mode testing as follows:	

OR

b. Continue with step 3.6

3.6 Cycles 5-6 LDB MODE Extended Temperature Test	3.6	Cycles	5-6	LDB	MODE	Extended	Tem	perature	Tests
---	-----	--------	-----	-----	------	----------	-----	----------	-------

1) Open chamber door	`.	Check:
(2) Install jumper to co	onfigure TDI board for LDB mode	Check:
(3) Set FIFO B interrupt	select dip switches to INT 11 (6 ON all others OFF).Check:
(4) If GSE is not power	ed, power GSE.	Check:
(5) If chamber is not po	owered, power chamber.	Check:
(6) Power the "Flight li	ke" CDM.	Check:\
a. FIFO LOAD b. MISSION M	tware setting software modes to O MODE=NORMAL ODE=LDB gle settings until get the above modes.	Check:
(8) Execute step 3.2 of	the LDB MODE SFT to verify Hard Reset status.	Check: Circle:PASS/FAIL
9) Execute step 3.3 of B.	LDB MODE SFT to exercise TDI in REALTIME mo	de with FIFO data on A and Check: Circle:PASS/FAIL
Toggle LDB M Toggle A DAT If necessary, to If necessary, to	ck mode with BERT on A and FIFO on B by: ODE to PLAYBACK A Source to BERT oggle A ENCODING to ENCODED oggle B DATA SOURCE to FIFO oggle B ENCODING to ENCODED gister to 0x4C	Check:
(11) II . (C. III D. I	. 1.1	
[11)Verify TDI is in the A1TLM:	a. Patch A1TLM to BS#1 S0 IN b. Enter 130 on bit sync to configure as follows: Data Rate: 300Ksymbols/sec Input Code: NRZ-L FEC Code: BPSK-D Rate: ½ c. Configure FIREBIRD 6000 for pattern 2047. Pred. Wait 2 minutes. e. Record Block Errors and Blocks:	
BITLM:	a. Patch B1TLM to BS#1 S0 IN b. Enter 134 on bit sync keypad to configure bit Data Rate: 100Ksymbols/Sec Input Code: NRZ-L FEC Code: BPSK-D Rate: 1/2	

	c. Configure FIREBIRD 6000 for pattern 63. Press d. Wait 2 minutes.	s REST ART
	e. Record Block Errors and Blocks:	SYNCLOSS
	ors is NON-ZERO for any reading OR Blocks is ZERO (OR SYNC LOSS light was
6	g.,	Check:
HOT Transition	(Powered)	
(12)At the thermal ch	namber, run profile starting at Profile Step 14.Date:	Time: Check:
(13)Set GN2 flow rate	to 10 cfh	Check:
	emperature display reaches 60 degrees, monitor A1TLM s. This is accomplished as follows: a. Patch A1TLM to BS#1 S0 IN b. Enter 130 on bit sync to configure as follows: Data Rate: 300Ksymbols/sec Input Code: NRZ-L FEC Code: BPSK-D Rate: ½ c. Configure FIREBIRD 6000 for pattern 2047. Press d. Wait 2 minutes. e. Record Block Errors and Blocks:	Restart.
A2TLM:	a. Patch A2TLM to BS#1 S0 IN. b. Press RESTART on FIREBIRD 60000 c. Wait 2 minutes. d. Record Block Errors and Blocks:	SYNCLOSS
B1TLM:	a. Patch B1TLM to BS#1 S0 IN b. Enter 134 on bit sync keypad to configure bit sy Data Rate: 100Ksymbols/Sec Input Code: NRZ-L FEC Code: BPSK-D Rate: ½ c. Configure FIREBIRD 6000 for pattern 63. Pres d. Wait 2 minutes. e. Record Block Errors and Blocks:	s REST ART
B2TLM:	a. Patch B2TLM to BS#1 S0 IN.b. Press RESTART on FIREBIRD 60000c. Wait 2 minutes.d. Record Block Errors and Blocks:	SYNCLOSS
light was on for a	ors is NON-ZERO for any reading OR Blocks is ZERO Cony of the above readings, then test failed.	Check:Circle:PASS/FAIL
(15)When TCs 2-5 av	verage 80 deg C +/- 2C, note date and time. Date:	Time: Check:

(16)Exit FLOW DAT	'A portion of the diagnostic software	Check:
(17)Execute steps 3.3	through 3.14 of LDB MODE SFT.	Check: Circle:PASS/FAIL
Select FLOW Enter: BERT Enter:BERT(If necessary, If necessary, If necessary, Set A Clock I Set B Clock I	ard for A Processor FIFO, B Processor BERT by exe DATA option of diagnostic software 9.BIN for FIFO A file name 5.BIN for FIFO B file name toggle A DATA Source to FIFO toggle A DATA Encoding to ENCODED toggle B DATA Source to BERT toggle B DATA Encoding to ENCODED Register to 0x4c Register to 0x 28 toggle LDB MODE to PLAYBACK	cuting the following:
		Check:
(19)Verify the TDI co A1TLM:	a. Patch A1TLM to BS#1 S0 IN b. Enter 134 on bit sync to configure as follow: Data Rate: 100Ksymbols/sec Input Code: NRZ-L FEC Code: BPSK-D Rate: ½ c. Configure FIREBIRD 6000 for pattern 511. P d. Wait 2 minutes. e. Record Block Errors and Blocks: a. Patch B1TLM to BS#1 S0 IN b. Enter 130 on bit sync keypad to configure b Data Rate: 300Ksymbols/Sec Input Code: NRZ-L FEC Code: BPSK-D Rate: ½ c. Configure FIREBIRD 6000 for pattern 2047 d. Wait 2 minutes. e. Record Block Errors and Blocks:	ress Restart SYNCLOSS oit sync as follows: . Press RESTART
COLD Transition	(Powered)	
	namber, run profile starting at Profile Step 18.Date:	Time: Check:
(21)Set GN2 flow rate	e to 5 cfh	Check:
· '	emperature is below –20 degrees, monitor A1TLM, A2' complished as follows: a. Patch A1TLM to BS#1 S0 IN b. Enter 134 on bit sync to configure as follows Data Rate: 100Ksymbols/sec Input Code: NRZ-L FEC Code: BPSK-D Rate: ½	

	c. Configure FIREBIRD 6000 for pattern d. Wait 2 minutes.	511. Press Restart.
	e. Record Block Errors and Blo	cks: SYNCLOSS
A2TLM:	a. Patch A2TLM to BS#1 S0 IN. b. Press RESTART on FIREBIRD 60000 c. Wait 2 minutes. d. Record Block Errors and Blo	
		STREEOSS
BITLM:	a. Patch B1TLM to BS#1 S0 IN b. Enter 130 on bit sync keypad to con Data Rate: 300Ksymbols/Sec Input Code: NRZ-L FEC Code: BPSK-D Rate: ½ c. Configure FIREBIRD 6000 for patter d. Wait 2 minutes.	n 2047. Press RESTART
	e. Record Block Errors and Blo	cks:SYNCLOSS
B2TLM:	a. Patch B2TLM to BS#1 S0 IN.b. Press RESTART on FIREBIRD 60000c. Wait 2 minutes.	
	d. Record Block Errors and Blo	cks:SYNCLOSS
	s is NON-ZERO for any reading OR Blocks y of the above readings, then test failed.	is ZERO OR SYNC LOSS light was
	<u>.</u>	Check:Circle:PASS/FAIL
(23)Wait for TCs 2-5 t	o average $-40 deg C +/- 2 C$. Note date and	ime.Date:Time:Check:
(24)Exit the FLOW DA	ATA section of the diagnostic software.	Check:
(25)Execute steps 3.3 t	hrough 3.14 of LDB MODE SFT.	Check: Circle:PASS/FAIL
Select the FLC Enter: BERT6 Enter:BERT9. If necessary, to If necessary, to Set A Clock re If necessary, to	oggle LDB MODE to REALTIME	re.
If necessary, to	oggle LDB STREAM to A	Check:
(27)Verify TDI configu	ration by:	
A2TLM:	a. Patch A2TLM to BS#1 S0 IN b. Enter 130 on bit sync to configure as Data Rate: 300Ksymbols/sec Input Code: NRZ-L FEC Code: BPSK-D Rate: ½	
	c. Configure FIREBIRD 6000 for pattern	US. FIESS KESTART.

	d. Wait 2 minutes. e. Record Block Errors	and Blocks:	SYNCLOSS
B2TLM:	a. Patch B2TLM to BS#1 5b. Press RESTART on FIR c. Wait 2 minutes.		
	d. Record Block Errors	and Blocks:	SYNCLOSS
			Check:
HOT Transition (Powered)		
(28)At the thermal ch	amber, run profile starting at F	Profile Step 23.Date:	Time: Check:
29)Set GN2 flow rate	to 10 cfh		Check:
(30) When chamber te	mperature display reaches 24 do	eg C and the RUN light i	s not lit, run Profile Step 14 Check:
	nperature exceeds 60 degrees, mo omplished as follows:	onitor A1TLM, A2TLM	, B1TLM and B2TLM for
A1TLM:	a. Patch A1TLM to BS#1	SO IN	
All LWI.	b. Enter 130 on bit sync to		
	Data Rate: 300Ksy		
	Input Code: NRZ-I		
	FEC Code: BPSK-I		
	Rate: ½		
		Of for pattern 62 Press	Dostart
	c. Configure FIREBIRD 600	00 for pattern 65. Press	Restart.
	d. Wait 2 minutes.	1.D11	GVANCE OGG
	e. Record Block Errors	and Blocks:	SYNCLOSS
A2TLM:	a Datah A2TIM to DC#1	CO IN	
AZI LIVI.	a. Patch A2TLM to BS#1 b. Press RESTART on FIR		
		EBIRD 60000	
	c. Wait 2 minutes.d. Record Block Errors	and Dla alsa	CVNCI OCC
	d. Record Block Ellors	and blocks	STNCLOSS
B1TLM:	a. Patch B1TLM to BS#1	SO IN	
DITLIVI.	b. Press RESTART on FIR		
	c. Wait 2 minutes.	EBIND 0000	
	d. Record Block Errors	and Blocks:	SYNCLOSS
	d. Record Block Ellors	und Diocks	511(02035
B2TLM:	a. Patch B2TLM to BS#1	SO IN.	
	b. Press RESTART on FIR	EBIRD 60000	
	c. Wait 2 minutes.		
	d. Record Block Errors	and Blocks:	SYNCLOSS
	rs is NON-ZERO for any readi		OR SYNC LOSS light was
light was on for al	ny of the above readings, then	test raned.	CI I
			Check:
			Circle:PASS/FAIL
(32)Wait for TCc 2 5	average 80deg C +/- 2 C. Not	e date and time Date:	Time
32) 11 an 101 1 Cs 2=3	average oddeg C 1/- 2 C. Not	e date and time.Date	Check:
			CHECK
(33)Set GN2 flow rate	to 5 cfh		Check:

(34)Exit FLOW DATA	section of diagnostic software.	Check:
(35)Execute steps 3.3 th	hrough-3.14 of LDB MODE SFT.	Check: Circle:PASS/FAIL
Select the FLO Enter: BERT 6. Enter:BERT 9. If necessary, to If necessary, to Set B Clock reg If necessary, to	rd for REALTIME B Processor FIFO by execut W DATA section of the diagnostic software. BIN for FIFO A data file. BIN for FIFO B data file. In the section of the diagnostic software. BIN for FIFO B data file. In the section of the se	ting the following: Check:
(37)Verify TDI board co	onfiguration by:	
A1TLM:	a. Patch A1TLM to BS#1 S0 IN	
	b. Enter 130 on bit sync to configure as follo Data Rate: 300Ksymbols/sec Input Code: NRZ-L FEC Code: BPSK-D Rate: ½	ws:
	c. Configure FIREBIRD 6000 for pattern 511	Press Restart.
	d. Wait 2 minutes. e. Record Block Errors and Blocks:_	SYNCLOSS
B1TLM:	a. Patch B1TLM to BS#1 S0 IN b. Press RESTART on FIREBIRD 6000 c. Wait 2 minutes. d. Record Block Errors and Blocks:_	SYNCLOSS
		Check:
COLD Transition (Powered)	
(38)At the thermal char	mber, run profile starting at Profile Step 18.Dat	e: Time: Check:
(39)When the chamber	temperature is below -20 degrees, monitor A1TLM	M A2TI M RITI M and R2TI M
	accomplished as follows:	,
A1TLM:	a. Patch A1TLM to BS#1 S0 IN b. Enter 130 on bit sync to configure as follo Data Rate: 300Ksymbols/sec Input Code: NRZ-L FEC Code: BPSK-D Rate: ½	ws:
	c. Configure FIREBIRD 6000 for pattern 511	Press Restart.
	d. Wait 2 minutes.e. Record Block Errors and Blocks:_	SYNCLOSS
A2TLM:	 a. Patch A2TLM to BS#1 S0 IN. b. Press RESTART on FIREBIRD 60000 c. Wait 2 minutes. d. Record Block Errors and Blocks:_ 	SYNCI OSS
	a. racora Block Birois and Blocks	511(01000)

BITLM:	a. Patch B1TLM to BS#1 S0 IN b. Press RESTART on FIREBIRD 6000 c. Wait 2 minutes. d. Record Block Errors and Blocks:	SYNCLOSS
B2TLM:	a. Patch B2TLM to BS#1 S0 IN.b. Press RESTART on FIREBIRD 60000c. Wait 2 minutes.	
	d. Record Block Errors and Blocks:	SYNCLOSS
	ors is NON-ZERO for any reading OR Blocks is ZERO any of the above readings, then test failed.	OOR SYNC LOSS light was
nght was on for t	any of the above readings, then test raised.	Check:
		Circle:PASS/FAIL
(40)Wait for TCs 2-:	5 average –40deg C +/- 2 C. Note date and time.Date:	Time: Check:
(41)Exit the FLOW D	OATA section of the diagnostic software.	Check:
(42)Execute steps 3.3	3 through 3.14 of LDB MODE SFT.	Check: Circle:PASS/FAIL
Select the FI Enter: BERT Enter:BERT If necessary, If necessary, If necessary, Set A Clock Set B Clock	oard for A Processor BERT, B Processor FIFO by exect OW DATA section of the diagnostic software. To BIN for FIFO A data file 9.BIN for FIFO B data file. 1. toggle A DATA Source to BERT 1. toggle A DATA Encoding to ENCODED 1. toggle B DATA Source to FIFO 1. toggle B DATA Encoding to ENCODED 2. toggle B DATA Encoding to ENCODED 3. Register to 0x4C 3. register to 0x28 3. toggle LDB MODE to PLAYBACK	
		Check:
	DI Configuration by: CLM:a. Patch A1TLM to BS#1 S0 IN b. Enter 134 on bit sync to configure as follows: Data Rate: 100Ksymbols/sec Input Code: NRZ-L FEC Code: BPSK-D Rate: ½ c. Configure FIREBIRD 6000 for pattern 2047. Pred. Wait 2 minutes. e. Record Block Errors and Blocks:	
віт	b. Enter 130 on bit sync keypad to configure bit Data Rate: 300Ksymbols/Sec Input Code: NRZ-L FEC Code: BPSK-D Rate: ½ c. Configure FIREBIRD 6000 for pattern 511. P d. Wait 2 minutes. e. Record Block Errors and Blocks:	Press REST ART

		Check:
AmbientTransitio	on (Powered)	
(45)At the thermal ch	amber, run profile starting at Profile Step 23.Date:	Time: Check:
(46)Set GN2 flow rate	to 10 cfh	Check:
	mperature is above 0 degrees, monitor A1TLM, A2TLM, B. omplished as follows: a. Patch A1TLM to BS#1 S0 IN	1TLM and B2TLM for
AITEM.	b. Enter 134 on bit sync to configure as follows: Data Rate: 100Ksymbols/sec Input Code: NRZ-L FEC Code: BPSK-D Rate: ½	
	c. Configure FIREBIRD 6000 for pattern 2047. Press Red. Wait 2 minutes. e. Record Block Errors and Blocks:	
A2TLM:	 a. Patch A2TLM to BS#1 S0 IN. b. Press RESTART on FIREBIRD 60000 c. Wait 2 minutes. d. Record Block Errors and Blocks: 	220 IDIVY2
BITLM:	a. Patch B1TLM to BS#1 S0 IN b. Enter 130 on bit sync keypad to configure bit sync Data Rate: 300Ksymbols/Sec Input Code: NRZ-L FEC Code: BPSK-D	
	Rate: ½ c. Configure FIREBIRD 6000 for pattern 511. Press d. Wait 2 minutes. e. Record Block Errors and Blocks:	
B2TLM:	 a. Patch B2TLM to BS#1 S0 IN. b. Press RESTART on FIREBIRD 60000 c. Wait 2 minutes. d. Record Block Errors and Blocks: 	_ SYNCLOSS
	ors is NON-ZERO for any reading OR Blocks is ZERO OR ny of the above readings, then test failed.	SYNC LOSS light was
, and the second		Check: Circle:PASS/FAIL
(48)Wait for TCs 2-5	to average 24deg C +/- 2 C. Note date and time.Date:	Time: Check:
49),Monitor A1TLM, A1TLM:	A2TLM, B1TLM and B2TLM for errors. This is accomplisa. Patch A1TLM to BS#1 S0 IN b. Enter 134 on bit sync to configure as follows: Data Rate: 100Ksymbols/sec Input Code: NRZ-L FEC Code: BPSK-D	shed as follows:

	Rate: ½					
	c. Configure FIREBIRD 6000	for pattern 2047. Pres	s Restart.			
	d. Wait 2 minutes.	1				
	e. Record Block Errors	and Blocks:	SYNCLOSS			
A2TLM:	a. Patch A2TLM to BS#1 S0 IN. b. Press RESTART on FIREBIRD 60000					
	c. Wait 2 minutes.	EDIKD 00000				
	d. Record Block Errors	and Blocks:	SYNCI OSS			
	u. Record block Effors	and blocks	511(CLOSS			
B1TLM:	a. Patch B1TLM to BS#1 S	0 IN				
	b. Enter 130 on bit sync ke	eypad to configure bit	sync as follows:			
	Data Rate: 300Ksy	mbols/Sec				
	Input Code: NRZ-L	i				
	FEC Code: BPSK-D)				
	Rate: 1/2					
	c. Configure FIREBIRD 600	00 for pattern 511. Pr	ess RESTART			
	d. Wait 2 minutes.	-				
	e. Record Block Errors	and Blocks:	SYNCLOSS			
B2TLM:	a. Patch B2TLM to BS#1 S					
	b. Press RESTART on FIRE	EBIRD 60000				
d. Wait e. Recor A2TLM: a. Patch b. Press c. Wait d. Recor B1TLM: a. Patch b. Enter c. Config d. Wait e. Recor B2TLM: a. Patch b. Press c. Wait d. Recor If Block Errors is NON-Z light was on for any of the ab	c. Wait 2 minutes.					
	d. Record Block Errors	and Blocks:	SYNCLOSS			
	is NON-ZERO for any readir		OR SYNC LOSS light was			
ngnt was on for any	of the above readings, then	test raned.	Check:			
			Circle:PASS/FAIL			
			Circle.F ASSTAIL			
(50)Power off the CDM	ſ		Check:			
(50)1 0 wer off the CDM	•		check			
(51)Run Profile Step 13	1.		Check:			
. , 1						
(52)Power down the GSI	Е.		Check:			
(53)Power down the the	ermal chamber.		Check:			
(54)Shut of GN2 purge t	to chamber.		Check:			
(55)Open chamber door	Check:					
(56)Disconnect thermo	couples from TDI		Check:			
(30)Disconnect thermo-	couples from 1 Dr.		CHECK			
(57)Disconnect GSE cal-	oles from TDI.		Check:			
(2.,= isconnect SBE ent						
(50)D EDIC						
(58)Remove TDI from	chamber.		Check:			

4. Declaration of Test Results

If there where no failures encountered during the execution of this test procedure that were not induced by procedural errors or GSE failures, then the TDI board in ULDB mode PASSES the TDI Prototype Thermal Test .

The test conductors and TDI system engineer declare that:

	Serial Number:	
PASSED/FAILED	O(Circle One) the TDI Prototype Thermal Test on	_(date)
Test Conductor	#1	
Test Conductor	#2	
TDI Systems En	gineer:	

_		 	 	 	 		
	Comments						
	GN2 Pressure Flow Rate						
	G Pressun						
	TC#6						
	TC#5						
:	TC#4						
1	TC#3						
1	TC#2						
1	TC#1						
	Cycle # Chamber Temp						
	Cycle #						
	Date/Time						

of.

Sheet:







